

Appendix A1

VERSION: REV. 01 - March 2015


Charger configuration is a simple step by step process as shown below.

For Tech Support call Enerdrive on **1300 851 535**

NOTE: The current setting below is based on the EN3DC30 battery charger.

DC2DC
ePOWER charger

Enerdrive
DRIVING YOUR ENERGY NEEDS



NOTE: At any function setting, pressing the **MENU** button will exit the function mode.

WARNING: FIRE HAZARD

When choosing the battery type and setting the charging parameter, please consult the battery manufacturer on all the voltage and current settings. Using the wrong setting to charge a battery may overcharge, damage the battery and may cause a fire.

*** Disregard the Temp Select setting if the Temperature Sensor is NOT connected.**