

Installation and Operation Guide


A qualified technician is required to install the Remote Panel to the DC2DC Charger. Take caution when working with batteries. Always disconnect the AC Power before you make any installation.

WARNING: Shock, fire and energy hazards.

This Remote Panel is to be used with the DC2DC series EN3DC30-24 and EN3DC40+ for single or parallel charger operation.

Mounting the Remote Panel:

- Choose an appropriate mounting location
- Use the wall cutout template and the Remote Panel mounting template as a reference to mark the positions of the mounting holes.



For use with the DC2DC series with single charger unit operation:

- Install the RJ45 Cable in your desired location.
- Connect one end of the RJ45 cable to 'Com 1' of Remote Panel. Please note the polarity.
- Secure the Remote Panel.
- Connect the other end of RJ45 cable to the 'Remote' port of the 12V DC2DC charger. Please note the polarity.
- The Remote Panel is now ready to use.

Understanding the Remote Panel function:

- The DC2DC Remote Panel share the same controls and display functions as the display on the DC2DC main unit.
- Please read "Understanding the Display & Function Keys during normal operation" for detail.

Warranty



5 Year Warranty

In the unlikely event that a technical issue arises with an ENERDRIVE | DOMETIC product, customers are encouraged to initially contact the ENERDRIVE | DOMETIC Support Team on 1300 851 535 or: support.enerdrive@dometic.com for immediate and efficient expertise and first class product support.

Important Note: Consumer Protections

If you have purchased your product in Australia, you should be aware that:

This warranty is provided in addition to other rights and remedies held by a consumer at law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

ENERDRIVE | DOMETIC warrants that its Products will be free from defects in materials and workmanship (subject to limits and in normal conditions, as described in the complete ENERDRIVE | DOMETIC Warranty Policy) for up to 5 years from the date of purchase.

For full terms, conditions and claim process, refer to the ENERDRIVE | DOMETIC website.

<https://enerdrive.com.au/warranty/>